



# Kayak Rack Instructions

Place the assembled racks onto the load bars. The load bars must be at least 24" apart

1. Line up the two Contour "J" Racks. With Bracket (#5) on the opposite side of the load bar, insert two (#8) bolts through the carrier rubber and into bracket (#5) and attaches with knobs (#7).

**NOTE:** The rack is supplied with two lengths of bolts. If bolts (#8) are too short, use the longer ones (#12)

2. Tighten all of the bolts include the ones that were hand tightened previously

## Loading Kayak

1. Run the webbing strap around the top of the carrier.
2. Load the kayak with the opening outward. Insure that all of the contact points on the kayak touch the pads.
3. Loop the straps over the kayak and around the load bars and tighten.
4. Attach the bow and stern tie downs to a secure point on the bumpers.

Check the lines regularly to ensure they are always tight.

## WARNINGS!

1. The load bars must be a minimum of 24" apart and kayak must be centered on the carriers. Do not exceed the factory recommended load on the crossbars.
2. Make sure the straps do not cover the cockpit area as it is not strong enough and damage can occur.
3. Always use the Bow and Stern lines and check regularly.
4. This rack is designed for Sea Kayaks and White water Kayaks. It is not designed for aluminum boats.

Part list		Qty
Description		
1. Tube Right		2
2. Tube Left		2
3. Carrier Rubber		2
4. Bracket		2
5. Bracket		2
6. High Density Foam		8
7. Knob with Nut (M8-1.25)		4
8. Inner Hexangular Bolt (M8x75-1.25)		4
9. Inner Hexangular Bolt (M8x35-1.25)		8
10. Nylon Nut (M8-1.25)		8
11. Strap (25 x 2800mm)		2
12. Bolt (M8x100-1.25)		4
13. Bow / Stern Line		2
14. Allen Hex Wrench		1

